

# Materials, Supplies & Cutting Diagram No. 151

## Classic Oak Tool Cabinet

<b>A</b>	Sides (2)	1 x 20 - 48	<b>X</b>	Drawer Bottoms (3)	1/4 ply. - 18 x 32 1/2
<b>B</b>	Top (1)	1 x 20 1/8 - 34 1/2	<b>Y</b>	Drawer False Front (1)	3/4 x 3 - 33 7/8
<b>C</b>	Horizontal Panels (3)	1 x 19 5/8 - 34 1/2	<b>Z</b>	Drawer Sides (2)	1/2 x 3 3/4 - 18 1/2
<b>D</b>	Vertical Divider (1)	1 x 3 5/8 - 19 1/4	<b>AA</b>	Drawer Front/Back (2)	1/2 x 3 3/4 - 32 1/2
<b>E</b>	False Tenons (16)	1/2 x 1 1/2 - 3/8	<b>BB</b>	Drawer False Front (1)	3/4 x 4 - 33 7/8
<b>F</b>	Apron (1)	1 x 3 1/2 - 34	<b>CC</b>	Drawer Sides (2)	1/2 x 5 1/4 - 18 1/2
<b>G</b>	Glue Blocks (2)	1 x 1 - 3	<b>DD</b>	Drawer Front/Back (2)	1/2 x 5 1/4 - 32 1/2
<b>H</b>	Back Stiles (2)	3/4 x 3 1/4 - 46 5/8	<b>EE</b>	Drawer False Front (1)	3/4 x 5 1/2 - 33 7/8
<b>I</b>	Back Top Rail (1)	3/4 x 5 1/2 - 29	<b>FF</b>	Tray Fronts/Backs (4)	3/4 x 2 - 31
<b>J</b>	Back Middle Rail (1)	3/4 x 5 - 29	<b>GG</b>	Tray Sides (4)	1/2 x 2 - 17 1/2
<b>K</b>	Back Bottom Rail (1)	3/4 x 7 1/2 - 29	<b>HH</b>	Tray Bottoms (2)	1/4 ply. - 17 x 30 1/2
<b>L</b>	Back Upper Panel (1)	1/4 ply. - 29 x 10 5/8	<b>II</b>	Tray Sub Bottoms (2)	1/4 ply. - 16 1/2 x 30
<b>M</b>	Back Lower Panel (1)	1/4 ply. - 29 x 19 5/8	<b>JJ</b>	Spacers (4)	1 x 2 - 18
<b>N</b>	Door Stiles (4)	3/4 x 3 - 23 7/8			
<b>O</b>	Door Center Stiles (2)	3/4 x 3 - 18 7/8			
<b>P</b>	Door Rails (4)	3/4 x 3 - 11 15/16			
<b>Q</b>	Door Panels (4)	1/2 x 4 27/32 - 18 7/8			
<b>R</b>	Small Drawer Sides (4)	1/2 x 2 3/4 - 18 1/2			
<b>S</b>	Small Drawer Fronts/Backs (4)	1/2 x 2 3/4 - 15			
<b>T</b>	Small Drawer Bottoms (2)	1/4 ply. - 18 x 15			
<b>U</b>	Small Drawer False Fronts (2)	3/4 x 3 - 16 3/8			
<b>V</b>	Drawer Sides (2)	1/2 x 2 3/4 - 18 1/2			
<b>W</b>	Drawer Front/Back (2)	1/2 x 2 3/4 - 32 1/2			

- (10) 1 1/4" -Dia. Bright Brass Knobs w/Screws
- (2 pr.) 2" x 1 3/8" Bright Brass Butt Hinges w/Screws
- (7 pr.) Accuride 18" Full-Extension Drawer Slides w/Screws
- (16) #8 x 2" Fh Woodscrews
- (20) #8 x 1" Fh Woodscrews
- (4) #8 x 1 3/4" Fh Woodscrews
- (8) #8 x 1 1/2" Ph Woodscrews
- (8) #8 x 7/8" Fender Washers
- (2) 1 3/4" x 5/16" Brass Ball Catches w/Screws

1" x 5 1/2" - 120" Quartersawn White Oak (8 Boards @ 5.7 Bd. Ft. Each)



1" x 5 1/2" - 96" Quartersawn White Oak (4.6 Bd. Ft.)



3/4" x 8" - 96" Quartersawn White Oak (5.3 Bd. Ft.)



ALSO NEEDED: One - 48" x 48" sheet  
1/4" quartersawn white oak plywood;  
One - 48" x 96" sheet 1/4" maple plywood


3/4" x 6" - 96" Quartersawn White Oak (4 Bd. Ft.)



3/4" x 6 1/2" - 96" Quartersawn White Oak (4.3 Bd. Ft.)



1/2" x 5" - 96" Quartersawn White Oak (3.3 Sq. Ft.)



3/4" x 5" - 72" Quartersawn White Oak (2.5 Bd. Ft.)



1/2" x 6" - 96" Hard Maple (4.0 Sq. Ft.)




1/2" x 6" - 96" Hard Maple (4.0 Sq. Ft.)



1/2" x 6" - 96" Hard Maple (4.0 Sq. Ft.)



1/2" x 8" - 60" Hard Maple (3.3 Sq. Ft.)



3/4" x 4 1/2" - 72" Hard Maple (2.3 Bd. Ft.)

